

## Ausbau ECU Yamaha Tenere 700

## ECU removal Yamaha Tenere 700

Die ECU der Yamaha Tenere 700 sitzt unterhalb der linken Heckverkleidung. Der Ausbau ist relativ unkompliziert und in 10 Minuten erledigt. Der Einbau erfolgt in umgekehrter Reihenfolge wie beschrieben

1. Zündung aus
2. Sitzbank demontieren
3. Batterie Pluspol abklemmen
4. Linke und rechte Verkleidungsteile vorne unterhalb der Sitzbank demontieren
5. Große Heckverkleidung demontieren
6. Die ECU sitzt auf der linken Fahrzeugseite.
7. Riegel am Stecker in Fahrtrichtung klappen
8. Stecker abziehen und ECU entnehmen.

The ECU of the Yamaha Tenere 700 is located underneath the left rear fairing. Removal is relatively uncomplicated and can be done in 10 minutes. The installation is done in the reverse order as described.

1. Ignition off
2. Remove the seat
3. Disconnect the cable from positive battery terminal
4. Remove the left and right fairings below tank / seat.
5. Remove the large rear fairing.
6. The ECU is located on the left side of the vehicle.
7. Fold the locking mechanism on the connector in the direction of travel.
8. Unplug the connector and remove the ECU.

