

# YAMAHA TENERE 700 HEADLIGHT INTERFACE MODULE

TENERE700-HLU-INTERFACE
USER'S MANUAL

## Colors of wires between the Headlight Interface Module and the headlight

Red	+12V high beam
Violet	+12V passing beam
Yellow	+12V parking light
Black	GND

All black GND wires are connected together - not depend which one is used for low beam and which one for high beam lamp.

#### Installation

- 1) Connect the Headlight Interface Module and the lights together using suitable connectors.
- 2) Connect the Headlight Interface Module to the original headlight socket.
- 3) Try the proper function and enjoy your new lights without errors.

#### Max allowed current draw

low beam wire: 8 A (ca 105 W)
high beam wire: 8 A (ca 105 W)
parking light wire: 3 A (ca 40W)

• for higher currents please use the relay and draw power directly from the battery

### Warranty

Product is covered by 2 years Limited Warranty (from the date of purchase). Limited Warranty covers any defects in material or manufacturing defects under normal use and maintenance. We reserve the right not to accept the claim in the case of mechanical damage that could be related to the defect of the product or if the product was disassembled by unauthorized service.



This limited warranty also does not cover any problem that is caused by conditions, malfunctions or damage not resulting from defects in material or workmanship.

During warranty period, we will repair or replace defective product or defective parts. To obtain warranty service, you must first contact us to determine the problem and the most appropriate solution for you.

Contact e-mail is: info@lskelectronics.com

#### Safety notice

Product should be installed by specialized garage or service. Inappropriate mounting or electrical connection may result in damaging this or any other electrical devices in the motorcycle.

Device has not been approved for using on public roads in EU. You are using device at your own risk and responsibility. We are also not responsible for any losses of the motorcycle warranty caused by install and use of this device.

#### Recycling

Retired device should be given to places specified for retrieving electrical garbage. Package should be thrown into a specific container for recycled garbage.

Device meets RoHS Directive.





#### Manufacturer



www.lskelectronics.com